

PROLINE™

ASSEMBLY INSTRUCTIONS: PL2KD

List of Parts:

- A X Brace w Trigger
- B Keyboard Support Bars (White Dot & Green Dot)
- C Base Support Bars (Pink Dot & Purple Dot)
- D Hex Head Screws (x4)
- E Allen Wrench

- Choose a large, flat and non-slip area on which to unpack and assemble your new stand. A carpeted surface works great!
- Start by laying out all the parts from the box and please notice the 4 sets of colored dots that are placed on each individual Part A through C.
- First pick up Part A and make sure that the trigger is oriented upwards and on your right side. Pull the trigger up and allow the X Brace to open 2 clicks. Stand up the now X Shaped brace on its 2 lower points and lean it against an appropriate surface for a moment. It should look like a standing X.
- Note: For reference, If facing the stand from the front (Trigger is on the right hand side) all Hex Screws will be inserted and tightened from the back of the stand and will not be on the side facing the user.
- Holding Part A in one hand pick up Part B with the White dot and place it over the shaft of Part A, matching up the dots as in Figure 1. Apply pressure to Part B till it completely settles onto the shaft of Part A. Tighten with 1 Hex Head Screw (Part D) using the included Allen Wrench (Part E).
- Then pick up Part B with the Green dots, again placing it over the remaining shaft of Part A also featuring green dots. Apply pressure to Part B till it completely settles onto the shaft of Part A. Tighten with 1 Hex Head Screw (Part D) using the included Allen Wrench (Part E).
- Next pick up the stand as it is and flip it upside down so that the Support Bars you just attached are now on the floor.
- Now pick up Part C with the Pink dots and place it over the shaft of Part A, matching up the dots as in Figure 1. Apply pressure to Part C till it completely settles onto the shaft of Part A. Tighten with 1 Hex Head Screw (Part D) using the included Allen Wrench (Part E).
- Finally, pick up Part C with the Purple dots and place it over the shaft of Part A, matching up the dots as in Figure 1. Apply pressure to Part C till it completely settles onto the shaft of Part A. Tighten with 1 Hex Head Screw (Part D) using the included Allen Wrench (Part E).

Your stand is now assembled and ready for use!

